



This NMO type antenna mounting bracket is designed for installation on these specific vehicles:

Ford F-150 Raptor 2010—2027

Model#: FRAPANTNCG

Tools Required:

10mm socket and driver, or 10mm box end wrench

Install location:

Fender bolt, driver side



Please Read: Always check for continuity between the bracket and chassis ground. If there is a problem with grounding, place the provided star washer between the bracket and the bolt head. To avoid galvanic corrosion, isolation material has been attached to the base of the FRAPANTNCG.

Step 1) Set the parking brake. Open hood and remove the bracket above the fender bolt on the driver side of the engine compartment. Remove bolt under the bracket.

Step 2) Align the antenna bracket with the bolt hole. Reinstall the bolt and tighten, reinstall the bracket and nut.

Step 3) Insert the NMO or required connector to mate with the antenna and tighten securely.



NCG Company may not be held liable for any damage to the vehicle before, during or after the installation or removal of this antenna bracket.
NCG may not be held liable for any personal injury resulting from accident or improper installation.



National Communications Group Co., Ltd
Chino, CA 800-962-2611
909-393-6133 Fax: 909-393-6136
www.natcommgroup.com